

CENG 3420

Computer Organization & Design



Lecture 18: Multi-Threading & Multi-Core

Bei Yu

CSE Department, CUHK

byu@cse.cuhk.edu.hk

(Textbook: Chapter 6)

2024 Spring



- ① Introduction
- ② Amdahl's Law
- ③ Thread-Level Parallelism (TLP)
- ④ Multi-Cores



Introduction



Doubling issue rates above today's 3-6 instructions per clock, say to 6 to 12 instructions, probably requires a processor to

- issue 3 or 4 data memory accesses per cycle,
- resolve 2 or 3 branches per cycle,
- rename and access more than 20 registers per cycle, and
- fetch 12 to 24 instructions per cycle.

The complexities of implementing these capabilities is likely to mean sacrifices in the maximum clock rate

- E.g, widest issue processor is the Itanium 2, but it also has the slowest clock rate, despite the fact that it consumes the most power



Amdahl's Law



Speedup due to enhancement E is


$$\text{Speedup w/ E} = \frac{\text{Exec time w/o E}}{\text{Exec time w/ E}}$$



Speedup due to enhancement E is

$$\text{Speedup w/ E} = \frac{\text{Exec time w/o E}}{\text{Exec time w/ E}}$$

Suppose that enhancement E accelerates a fraction F ($F < 1$) of the task by a factor S ($S > 1$) and the remainder of the task is unaffected



$$\text{ExTime w/ E} = \text{ExTime w/o E} * ((1-F) + F/S)$$

$$\text{Speedup w/ E} = 1 / ((1-F) + F/S)$$

Example 1: Amdahl's Law



Consider an enhancement which runs 20 times faster but which is only usable 25% of the time.

Speedup w/ E =

What is its usable only 15% of the time?

Speedup w/ E =



- A scalar processor processes only **one datum** at a time.
- A vector processor implements an instruction set containing instructions that operate on **one-dimensional** arrays of data called **vectors**.

Example 2: Amdahl's Law



Consider 10 scalar variable summings and two 10 by 10 matrices (matrix sum) on 10 processors

Speedup $w/E =$

What if there are 100 processors ?

Speedup $w/E =$

What if the matrices are 100 by 100 (or 10,010 adds in total) on 10 processors?

Speedup $w/E =$

What if there are 100 processors ?

Speedup $w/E =$



- To get a speedup of 90 from 100 processors, the percentage of the original program that could be scalar would have to be 0.1% or less
- Amdahl's Law tells us that to achieve linear speedup with 100 processors, none of the original computation can be scalar!



Thread-Level Parallelism (TLP)



- Difficult to continue to extract instruction-level parallelism (ILP) from a single sequential thread of control
- Many workloads can make use of thread-level parallelism (TLP)
- TLP from [multiprogramming](#) (run independent sequential jobs)
- TLP from [multithreaded applications](#) (run one job faster using parallel threads)
- Multithreading uses TLP to improve utilization of a single processor



A web browser

- One thread displays images
- One thread retrieves data from network

A word processor

- One thread displays graphics
- One thread reads keystrokes
- One thread performs spell checking in the background

A web server

- One thread accepts requests
- When a request comes in, separate thread is created to service
- Many threads to support thousands of client requests



Find a way to “hide” true data dependency stalls, cache miss stalls, and branch stalls by finding instructions (from other process threads) that are independent of those stalling instructions

Hardware Multithreading

Increase the utilization of resources on a chip by allowing multiple processes (threads) to share the functional units of a single processor


- Processor must duplicate the state hardware for each thread – a separate register file, PC, instruction buffer, and store buffer for each thread
- The caches, TLBs, BHT, BTB, RUU can be shared (although the miss rates may increase if they are not sized accordingly)
- The memory can be shared through virtual memory mechanisms
- Hardware must support efficient thread context switching

Multithreaded Example: Sun's Niagara (UltraSparc T2)



Eight fine grain multithreaded single-issue, in-order cores (no speculation, no dynamic branch prediction)


	Niagara 2
Data width	64-b
Clock rate	1.4 GHz
Cache (I/D/L2)	16K/8K/4M
Issue rate	1 issue
Pipe stages	6 stages
BHT entries	None
TLB entries	64I/64D
Memory BW	60+ GB/s
Transistors	??? million
Power (max)	<95 W



Niagara Integer Pipeline



Cores are simple (single-issue, 6 stage, no branch prediction), small, and power-efficient





Coarse-grain

Switches threads only on costly stalls (e.g., L2 cache misses)

- 😊 Thread switching doesn't have to be essentially free and much less likely to slow down the execution of an individual thread
- ☹️ Limited, due to pipeline start-up costs, in its ability to overcome throughput loss
- ☹️ Pipeline must be flushed and refilled on thread switches

Fine-grain

Switch threads on every instruction issue


- **Round-robin** thread interleaving (skipping stalled threads)
- Processor must be able to switch threads on every clock cycle
- 😊 Can hide throughput losses that come from both short and long stalls
- ☹️ Slows down the execution of an individual thread since a thread that is ready to execute without stalls is delayed by instructions from other threads




A variation on multithreading that uses the resources of a multiple-issue, dynamically scheduled processor (superscalar) to exploit both program **ILP** and **TLP**

- Most SS processors have more machine level parallelism than most programs can effectively use (i.e., than have ILP)
- With register renaming and dynamic scheduling, multiple instructions from independent threads can be issued without regard to dependencies among them
- Need separate rename tables (**RUUs**) for each thread or need to be able to indicate which thread the entry belongs to
- Need the capability to commit from multiple threads in one cycle
- Intel's Pentium 4 SMT is called **hyperthreading**: supports just two threads (doubles the architecture state)


Threading on a 4-way SS Processor Example



Threading on a 4-way SS Processor Example



Threading on a 4-way SS Processor Example



Threading on a 4-way SS Processor Example






Figure 3. TPU Printed Circuit Board. It can be inserted in the slot for an SATA disk in a server, but the card uses PCIe Gen3 x16.





Figure 4. Systolic data flow of the Matrix Multiply Unit. Software has the illusion that each 256B input is read at once, and they instantly update one location of each of 256 accumulator RAMs.






Multi-Cores



Multiprocessor

A computer system with at least two processors



- Can deliver high throughput for independent jobs via **job-level parallelism** or **process-level parallelism**
- And improve the run time of a single program that has been specially crafted to run on a multiprocessor – a **parallel processing program**



- Power challenge has forced a change in microprocessor design
- Since 2002 the rate of improvement in the response time of programs has slowed from a factor of 1.5 per year to less than a factor of 1.2 per year
- Today's microprocessors typically contain more than one core – **Chip Multicore microProcessors (CMPs)** in a single IC

Product	AMD Barcelona	Intel Nehalem	IBM Power 6	Sun Niagara 2
Cores per chip	4	4	2	8
Clock rate	2.5 GHz	~2.5 GHz?	4.7 GHz	1.4 GHz
Power	120 W	~100 W?	~100 W?	94 W



- Some of the problems that need higher performance can be handled simply by using a **cluster**
- A set of independent servers (or PCs) connected over a local area network (LAN) functioning as a single large multiprocessor
- E.g.: Search engines, Web servers, email servers, databases ...

Key Challenge

Craft parallel (concurrent) programs that have high performance on multiprocessors as the number of processors increase

E.g.: Scale Scheduling, load balancing, time for synchronization, overhead for communication



To get good speedup on a multiprocessor while keeping the problem size fixed is **harder** than getting good speedup by increasing the size of the problem.

- **Strong scaling** – when speedup can be achieved on a multiprocessor without increasing the size of the problem
- **Weak scaling** – when speedup is achieved on a multiprocessor by increasing the size of the problem proportionally to the increase in the number of processors

Load balancing is another important factor. Just a single processor with twice the load of the others cuts the speedup almost in half



Q1: How do they share data?

Q2: How do they coordinate?

Q3: How scalable is the architecture? How many processors can be supported?



Q1: How do they share data?

Single address space shared by all processors

Q2: How do they coordinate?

Processors coordinate/communicate through **shared variables** in memory (via loads and stores)

- Shared data coordinated via **synchronization primitives** (locks) that allow access by only one processor at a time



2 Multiprocessor Styles:

- Uniform memory access (UMA)
 - Nonuniform memory access (NUMA)
-
- Programming NUMAs are **harder**
 - But NUMAs can scale to larger sizes and have lower latency to local memory



- Need to be able to coordinate processes working on a common task
- Lock variables (**semaphores**) are used to coordinate or synchronize processes

Need an architecture-supported **arbitration** mechanism


- decide which processor gets access to the lock variable
- **Single bus** provides arbitration mechanism, since the bus is the only path to memory
- The processor gets the bus wins

Need an architecture-supported **operation** that

- locks the variable
- Locking can be done via an **atomic swap operation**



The single **winning** processor will succeed in writing a **1** to the lock variable; all others processors will get a return code of **0**





- Processors start by running a loop that sums their subset of vector A numbers
- Vectors A and sum are **shared** variables
- P_n is the processor's number, i is a private variable

```
sum[Pn] = 0;
for (i=1000*Pn; i<1000*(Pn+1); i=i+1)
{
    sum[Pn] = sum[Pn] + A[i];
}
```




- The processors then coordinate in adding together the partial sums
- `half` is a **private** variable initialized to 100 (the number of processors))

```
repeat
    synch();           //synchronize first
    if (half%2 != 0 && Pn == 0) {
        sum[0] = sum[0] + sum[half-1];
    }
    half = half/2
    if (Pn<half) {
        sum[Pn] = sum[Pn] + sum[Pn+half]
    }
until (half == 1); //final sum in sum[0]
```

An Example with 10 Processors




sum[P0]sum[P1]sum[P2] sum[P3]sum[P4]sum[P5]sum[P6] sum[P7]sum[P8] sum[P9]





- `synch ()`: Processors must synchronize before the “consumer” processor tries to read the results from the memory location written by the “producer” processor
- **Barrier synchronization**: a synchronization scheme where processors wait at the barrier, not proceeding until every processor has reached it





Barrier Implemented with Spin-Locks

- `n` is a **shared** variable initialized to the number of processors
- `count` is a **shared** variable initialized to 0
- `arrive` and `depart` are **shared** spin-lock variables where `arrive` is initially unlocked and `depart` is initially locked

```
procedure synch()
{
    lock(arrive);
    count = count + 1; // count the processors as
    if (count < n) { // they arrive at barrier
        unlock(arrive)
    }
    else {
        unlock(depart);
    }
    lock(depart);
    count = count - 1; // count the processors as
    if (count > 0) { // they leave barrier
        unlock(depart)
    }
    else {
        unlock(arrive);
    }
}
```



With a bus based cache coherency protocol (write invalidate), spin-locks allow processors to wait on a local copy of the lock in their caches

Reduces Bus Traffic

Once the processor with the lock releases the lock (writes a 0) all other caches see that write and invalidate their old copy of the lock variable. Unlocking restarts the race to get the lock. The winner gets the bus and writes the lock back to 1. The other caches then invalidate their copy of the lock and on the next lock read fetch the new lock value (1) from memory.

This scheme has problems scaling up to many processors because of the communication traffic when the lock is released and contested



Each processor has its own private address space

Q1: How do they share data?


Processors share data by **explicitly** sending and receiving information (**message passing**)

Q2: How do they coordinate?

Coordination is built into message passing primitives (**message send** and **message receive**)



Each processor has its own private address space





Start by distributing 1000 elements of vector A to each of the **local** memories and summing each subset in parallel


```
sum = 0;
for (i = 0; i<1000; i = i + 1)
{
    sum = sum + A[i]; // sum local array subset
}
```



- The processors then coordinate in adding together the sub sums
- P_n is the number of processors
- `send(x, y)` sends value y to processor x , and `receive()` receives a value

```
half = 100;
limit = 100;
repeat {
    half = (half+1)/2; //dividing line
    if ( $P_n \geq$  half &&  $P_n <$  limit) send( $P_n$ -half, sum);
    if ( $P_n <$  (limit/2)) sum = sum + receive();
    limit = half;
} until (half == 1); //final sum in P0's sum
```

An Example with 10 Processors





- 😊 Message passing multiprocessors are much easier for hardware designers to design
- 😊 Don't have to worry about cache coherency for example
- 😊 The advantage for programmers is that communication is explicit, so there are fewer "performance surprises" than with the implicit communication in cache-coherent SMPs.
- 😞 Message sending and receiving is much slower than addition
- 😞 Harder to port a sequential program to a message passing multiprocessor since every communication must be identified in advance ¹.

¹With cache-coherent shared memory, the hardware figures out what data needs to be communicated



- Q1: How do they share data?
- Q2: How do they coordinate?
- Q3: How scalable is the architecture? How many processors?

		# of Proc	
Communication model	Message passing		8 to 2048
	Shared address	NUMA	8 to 256
		UMA	2 to 64
Physical connection	Network		8 to 256
	Bus		2 to 36