

- In a physical communication system, the input and output of a channel often take continuous real values.
- A **waveform channel** is one such that transmission is in continuous time.
- At the physical layer, we need to deal with channels such that the values taken are continuous and transmission is in continuous time.